

# MIST NOZZLE KIT

## Installation Instruction

---

1. Please replace the normal tube with the thinner sanitizer tube. This needs to be done because larger tubes have a higher flow rate, causing relatively high backpressure which will shorten tube life.
2. Attach the end of the transport tube from the pump to the 90° compression fitting.
3. Remove the protective cover from the nozzle.



*Mist can collect on surfaces possibly creating a slip hazard, and care should be taken with potentially flammable products, since this system may increase their flammability.*