

# *How to Use DuoClean*



***Beta***


# Contents of presentation

- DuoClean Assembly
- Putting clothes on the DuoClean
- Using DuoClean to dust
- Sweeping debris into DuoClean
- Depositing debris in trash bin



*Box of 500 DuoClean microfiber cloths*

# DuoClean Assembly



*Mop handle clip attached to DuoClean*

- DuoClean can be used with standard “clip on” mop handles. These have an advantage over screw in handle types, which often screw out during use
- Use the mop handle clip to attach to the DuoClean bar
- Attach the DuoClean broom to the mop handle using the black plastic clip, which fits over both

# Assembling cloths on DuoClean

- DuoClean clothes come in 12" (30cm) lengths
- To assemble onto a small 24" DuoClean, pull 24" of cloth, or two lengths from the box of DuoClean clothes
- Do not separate the lengths into individual 12" pieces; they must be connected and the same length as the DuoClean
- Fit the cloths over the front tabs of the DuoClean
- Wrap around the bottom of the DuoClean
- Secure the clothes using the two tabs on the back of the DuoClean
- Use a 48" length of cloth for the large DuoClean



*Two DuoClean cloths assembled onto front plastic tabs of a 24" DuoClean*



*Two DuoClean cloths assembled over the bottom of a 24" DuoClean*

# Using DuoClean to Dust



How to Use DuoClean

- Push DuoClean forward across the floor
- The micro fiber DuoClean cloths will pick up the dust
- Debris such as wood chips, loose papers etc. can be pushed in front of DuoClean as with any dust mop, and swept in at the end of an aisle or whenever is convenient
  
- Up to three layers of cloths can be attached at once if necessary for a very large floor surface

**Beta**

# Sweeping debris into DuoClean

- When you reach the end of an aisle or have a lot of debris, such that some goes off the edge when you make turns, it's time to sweep up the debris
- Unclip the broom
- Sweep debris into DuoClean
- As with any dustpan, move DuoClean back an inch or so and resweep once or twice to get all the debris
- ***Never shake DuoClean up and down to loosen dust, as many users do with other dust mops. Doing so will not damage the DuoClean, but with any dust mop this tends to make microscopic amounts of dust spread all around, up to 6' in the air***



# Depositing Debris in Trash Can



- To dump debris, just pivot DuoClean over a trash can
- The unit is designed so all the debris will slide to one end and into the trash can, so it's quick and ergonomically friendly

# Removing DuoClean cloths



- When the cloth is dirty, dump debris into a trash bin, and pull the cloth off the tabs
- The cloth is thrown away with the debris; it isn't laundered and reused, so you have a fresh cloth every time!

# *How to Use DuoClean*



***Beta***