



BoilerMatic 3000/4000 or Exactrol PCB Replacement



DESCRIPTION

If you have a older BoilerMatic 3000/4000 or an Exactrol that used mounting rails for the power PCB, you will need to use the provided standoffs and lock washers to install the new version power PCB (P/N #099532).

REPLACEMENT INSTRUCTIONS

1. Remove defective power PCB from unit by removing the screws holding PCB to mounting rails. Save screws for installing replacement power PCB.
2. Install provided standoffs (4 each, P/N #041163) into the Tinnerman clips located on the mounting rails and tighten.
3. Install new power PCB by positioning the PCB over the standoffs.
4. Secure PCB with lockwashers (4 each, P/N #027176) and screws removed earlier.



Beta Technology, Inc
2841 Mission Street
Santa Cruz • CA
U.S.A. • 95060

TEL • 831 • 426 • 0882
TEL • 800 • 858 • 2382
FAX • 831 • 423 • 4573
FAX • 800 • 221 • 8416
Customer Service
TEL • 800 • 468 • 4893 Tech Support
sales@beta-technology.com

Beta Technology, Inc
4 Finway, Dallow Road
Luton LU1 1TR
United Kingdom

Freephone • 0800 • 052 • 4726
Tel • +44(0) • 1582 • 528600
Fax • +44(0) • 1582 • 528111
Customer Service
Freephone • 0800 • 052 • 4726 Tech Service
VAT REG.NO.BG.354 - 09975 - 44
europe.sales@beta-technology.com

Online Ordering: <http://www.beta-technology.com>