

Equipment Technical Bulletin

New 600 Series Viton Tube Roller



PROBLEM

Over the past few years, customers have occasionally had difficulty running Viton tube in 600 Series pumps because the Viton tube is so stiff. When experiencing this problem, the roller may turn without pumping product because the springs aren't strong enough to compress the tube.

SOLUTION

When using Viton tubing in 600 Series pumps, lubricate the entire tube with Vaseline, and use special Viton tube roller, Code Number 1202764, which has stronger springs to compensate for the harder tube.



Beta Technology
2841 Mission Street
Santa Cruz • CA
U.S.A. • 95060

TEL • 831 • 476 • 0882
TEL • 800 • 858 • 2382
FAX • 831 • 423 • 4573
FAX • 800 • 221 • 8416

Customer Service

TEL (U.S. and Canada) • 800 • 168 • 4893
TEL (outside U.S. and Canada) • 410 • 228 • 1292

Tech Support

sales@beta-technology.com

Beta Technology

4 Finway, Dallow Road
Luton LU1 1TR
United Kingdom

Freephone • 0800 • 052 • 4726
Tel • +44(0) • 1582 • 528600
Fax • +44(0) • 1582 • 528111

Customer Service

Freephone • 0800 • 052 • 4726
VAT REG. NO. BG.354 - 09775 - 44

europa.sales@beta-technology.com

Online Ordering: <http://www.beta-technology.com>

Beta Technology is ISO9001 Certified